





Geometry Data - the basics Cross-section information Roughness coefficients Distance between sections Bridge/culvert data

Cross Section Locations

Place and measure cross sections when there is a change in:

Slope

O^E

- Discharge
- Roughness
- Channel shape
- Control (bridge, levee, weir, etc)







Survey

- Survey shots must describe the channel and overbank flow area
- Section should extend across the entire floodplain
- Plot cross-section data, especially electronic surveys
- Take photographs

- Assume modeler has never seen the stream
- Note vegetation changes in cross-section e.g. field, trees, grass buffer, etc.
- No 3-point cross-sections









Then enter p	roject title and fil	e name
lew Project		
Title	File Name	Directories
		C\ PROGRA~1 HEC RAS
		Steady
OK Cancel	Help Create Directory	Steady





Stream Geometry Data

6

- Suggested order of data entry:
 - Add River Reach(es) along with any Junctions (actually, this must be first).
 - Add Cross-Section names, elevation-station data, 'n' values, bank stations, reach lengths, loss coefficients, etc.
 - Add Road/Bridge/Culvert and/or Weir/Spillway data.



River System Schematic

- Must be added before any other features.
- Draw and connect the reaches of the stream system.
- Draw from upstream to downstream, which will coincide with a flow direction arrow - generally from top of screen to bottom. Double click on last point to end.
- Connection of 3 reaches is a junction.

- Can model from single reach to complicated networks. The river can even split apart and then come back together.
- Can accentuate by adding background bitmap.



















Entering Cross Section Data

- Other but present sections can be shown in the same plot.
- Ideal to check relative shape and elevation differences.



Notes on Cross-Section Data (cont)

- Location of X-sections within a reach varies with the intensity of the study and the conditions of the reach
- The choice of friction loss equations will also affect X-section spacing and predicted flood elevations
- Higher number X-section river stations are assumed to be upstream of lower number river stations. Slope areas require more X-sections.
- The left side of the X-section, looking downstream, is assumed to have the lower X values and progress right as the X values increase, (can not narrow the section)



Notes on Cross-Section Data

- X-sections should extend across the entire floodplain and be perpendicular to anticipated flow lines (approximately perpendicular to ground contour lines).
- X-sections should accurately represent stream and floodplain geometry. Put in where changes occur in discharge, slope, shape, roughness, and bridges.
- Enter X-Section elevation-station data from left to right as seen when looking downstream.
- Cross-Sections should start far enough downstream to "zero out" any errors in boundary conditions assumptions (for sub-critical profile). Far from upstream for super-critical flow. The section of analysis should be farm from boundary errors.









Notes on Cross-Section Data (cont.) • HEC-RAS has an option to create interpolated cross sections. It can be used to create more "in between" sections as long as there are not section singularities. 🔨 Geometric Data - sugar crk rock chute - model adjusted... 💶 🗖 🗙 By reach <u>File Edit View Tables Tools Options Help</u> Within a Beach ... XS Interpolatic XS Interpolation by Reach Ed Between 2 🛛 S's ... Channel Modification Graphical Cross Section Edit Junct. Asaayi • River: Reverse Stationing Data Set Ineffective Areas to Permanent Mode Wash 1 • Reach: Cross Section Cross Section Points Filter Fixed Sediment Elevations (All RS) • Upstream Riv Sta: Pilot Channels Brdg/Cul GIS Cut Line Check Downstream Riv Sta: (All RS) -Maximum Distance between XS's: 2 Decimal places -Delete Interpolated XS's Interpolate XS's **O** Close Help Enter max distance between interp XSs.



Expansion & Contraction Coefficients

	Contraction	Expansion
No Transition	0.0	0.0
Gradual Transition (default)	0.1	0.3
Typical Bridge Transition	0.3	0.5

- Typical values for gradual transitions in supercritical flow are 0.05 for contraction and 0.10 for expansions.
- Constructed prismatic channels should have expansion and contraction coefficients of 0.0

Ineffective Flow Areas

0

0

- Two types of Ineffective Flow Areas :
 - 1. Normal where you supply left and right stations with elevations which block flow to the left of the left station and to the right of the right station
 - 2. Blocked where you can have multiple (up to 10) blocked flow areas within the X-section

Ineffective Flow Areas

- Ineffective flow areas are used to model portions of the cross-section in which water will pond, but the velocity of that water in the downstream direction is equal to zero.
- This water is included in the storage and wetted cross section parameters, but not in the active flow area.
- No additional wetted parameter is added to the active flow area (unlike encroachments).
- Once ineffective flow area is overtopped, then that specific area is no longer considered ineffective.
- Commonly used in culverts, near road crossings.

ITC























Levees Option is from x-section window... Cross Section Data - St Croix EWP revised which brings up this Exit Edit Options Plot Help window: Add a new Cross Section . St Apply Data | 🤜 + 🚥 Copy Current Cross Section . • **J T** St Reacht Rename River Station ... XS Levee Data Delete Cross Section Del Row Adjust Elevations . nter station and elevation points to mark leve Channel ROB Adjust Stations Cro Adjust <u>n</u> or K values . 63 63 Left Right Skew Cross Section .. 1 100 400 800 12 Station Channel ROB Ineffective Flow Area: 96 94 3 400 Elevation 0.04 0.07 Levees 4 571 Cancel Defaults Clear OK 582 Obstructions Add a Lid to XS ... Bank Right Bank 590 003 Add Ice Cover .. 633 610 Add a Rating Curve . 12 618 ction Expansi Horizontal Variation in n Values 10 633 0.3 Horizontal Variation in <u>K</u> Values Vertical Variation in n Values . Select river for cross section editing

Levees vs. Ineffective Flow Areas

- Are conceptually similar but very different hydraulically
- Ineffective flow areas is used where water is present to the left/right of the ineffective station but the velocity is zero. Volume included in storage and wetted perimeter calculations but not in conveyance. (think: ponded area)
- A levee acts as a vertical wall. No water occupied the space to the left/right of the levee unless the levee elevation is exceeded. The distance that the levee is in contact with the water is included in the wetted perimeter calculations. (think: wall)

ITC Faculty of Geo-Information Science and Earth Observation of the University of Twente



Ent	er Flow Data	
Enter	the Steady Flow Dat	a Editor from the main menu
HEC-RAS File Edit Bu Geome Steady Proje Unstea	- River Analysis System n View Options Help tric Data Flow Data dy Flow Data eometry	C \\west manual\seeley1.prj
Plan: Sedme Geometry: Steady Flow:	nt Data seeley creek FIS study run dated 9 dec87 Flow 01	C:\wes manual\seeley\seeley1.p01 C:\wes manual\seeley\seeley1.g01 C:\wes manual\seeley\seeley1.f01
Unsteady Flow: Project Description :	using FIS geometry	US Customary Units
Or, yo Flow	pung FIS geometry ou can select the Ste Data button:	ady
9		







Enter Flow Data: Boundary Conditions
Set the boundary conditions by selecting "Reach Boundary Conditions" " This brings up Steady Flow Boundary Conditions window. You can set the boundary for all profiles at once, or separately.
Pady Flow Data Options Help Ecot Number of Profiles (100 max): Ecot Number of Profiles (100 max): Ecot Number of Profiles (100 max): Ecot Number of Flow Data Changes Ecot Number of Flow Data Changes Ecot Number of Profile Numes and Ecot Number of Ecotion Ecot Number of Ecotion Ecot Number of Ecot Number of Ecot Number of Ecot
Reach RS PF 1 Steady Flow Boundary Conditions fest Main 20.05 100 © Set boundary for one profile at a time
iest Main 18 120 Available External Boundary Condition Types
Known W.S. Critical Depth Normal Depth Rating Curve Delete
Selected Boundary Condition Locations and Types
River Reach Profile Upstream Downstream
Bready How Headmatorage Area Uptimization

Enter Flow Data User can add flow changes at a certain station along one certain reach. Select River Station Click "Add a Flow Change Location", and select the station and enter the added flow to the reach. • NOTE: Normally the flow input will be required at least in the most upstream section of each river branch (program default). Steady Flow Data - trial 1 Reach Boundary Conditions Inter/Edit Number of Profiles (2000 mast: 3 iver: Mill Creek Beach: project an Biver Sta Add A Flow Change Location Steady Flow Data ter/Edit Number of Profiles (100 max) 3 Reach Boundary Conditions Apply Data rr Sta: 18 • Add A Flow Change Location 6 ITC



Enter Flow Data • After selecting either the upstream or downstream data box and then selecting method for providing starting conditions, a window appears for entering your data. Boundary conditions are entered: downstream end for sub-critical flow upstream end for super-critical • both for mixed (when in the reach there are both sub- and super-critical sections) C Set boundary for one profile at a time • Set boundary for all profiles Known W.S. Critical Depth Normal Depth Rating Curve Delete HEC-RAS Mill Creek project nter the project area for all profile

Cancel

OK Cancel Help

OK

^عار کا

Enter Flow Data	ta - Observed Water Sur	faces
Enk Undo Edis Delete Row From Table Delete Al Rows from Table Rive Delete Column (Porile) From Table Ree Baito Selected Flows Edit Profile Names Qbearved WS Qbearved Raing Curves (Gages) Gate Opermap	 A menu appears. Select Obs A menu appears. Select River Select "Add an Obs WS Location Enter observed elevation. The observation of the water must be in accordance with the select of the select o	Station on" elevation ne profile
	Observed Water Surfaces for Comparison	
	River: Mill Creek	Delete Row
	Reach: project area 💌 River Sta.: 97.*	Add an Obs. WS Location
	Obterved WS Locs 97.* ▲ River Reach R 96.5* ■ 1 Mil Creek project area 100 95.5* ■ 2 Mil Creek project area 97.* 95.* ■ 34.* 93.5* ■ ■ ■	Observed Water

Enter Flow Data • There are several options available in the "Options" window of the Steady Flow Data window such as changing profile names, applying a ratio to all flows, etc. Make a consultation of the manual for details. Elle Options Help Delete Row From Tab _ 🗆 × Steady Flow [File Options He Enter/Edit Number of Profiles (2000 max): 1 ул 25 ул Reach Istudureach ▼ River Sta.: ation .33 yr 1556 6 • OK Cancel













Perform the Hydraulic Computations

- There are several options available for the hydraulic computations
 - User must refer to the manual for details























View th	ne Outp	ut							
	File Output	t Table - Stan d. Tables <u>L</u> oca	<mark>dard Tab</mark> tions <u>H</u> elp	e 1	_		_		
	HE	C-RAS Plan: mo	d1 River:	Mill Creek	Reach: pro	ject area		Reload	Data
	Reach Rive	Sta Profile	Q Total	Min Ch El	W.S. Elev	Crit W.S.	E.G. Elev	E.G. Slope	V.
			(cfs)	(ft)	(ft)	(ft)	(ft)	(ft/ft)	
	project area 100	500cfs	500.00	418.20	421.76		421.95	0.001709	
	project area 100	2000cfs	2000.00	418.20	425.53		425.96	0.001791	
	project area 100	7000cfs	7000.00	418.20	431.76	-	432.59	0.001766	
	project area 99.5	500cfs	500.00	418.03	421.59		421.77	0.001713	_
	project area 99.5	2000cfs	2000.00	418.03	425.36		425.79	0.001794	
	project area 99.5	1 7000cfs	7000.00	418.03	431.59		432.42	0.001767	-
	•		reate a T	able Headi	ng				
			Select Va	nables Add	itional Options	1			
	I otal flow in cross :	section.			T	able Column H	leadings		
	12		Column	1		2	3	4	5
Under "Opt	ions", select "	Define	Variable	QTo	tal Min	Ch El \	N.S. Elev	Crit W.S.	E.G. Elev
Table" to s	ee more variabl	PS	Decimal F	ts 2	,	2	2	2	2
		05	•	ata Caluma		laura Cal		Class All Ta	<u>}</u>
			00	ete column		Available Va	ishlar		ole medulings
9			# Barrels Alpha Area Area Char Area Left Area Righl	Base Beta BR C BR C Br Se C & E	rWS Open Area Open Vel el Method Loss	Center Station Ch Sta L Ch Sta R Clv EG No W Coef of Q Conv. Chnl	n Conv. Lo Conv. R Conv. R r Conv. T Crit Dep Crit E.G.	eft Criti atio Criti ight Criti otal Criti th Criti Criti	Enrgy 1 Enrgy 2 Enrgy 3 Num W.S. W.S. 1
ITC			4	-					F

Generate Reports	Bit ECRAS - Five Analysis System Fig. Est. Bit. Wav. Dolona. Help Ihrer Pripet. Dere Pripet. Sare Project.
 You can select "Generate 	Project Surmay [Import HEC 22 Dat Import HEC PAS Data
Report" from the HEC-RAS	Ennetade Report Export GIS Data Export to HEC⊉SS Restore Data ►
main menu.	Report Generator C:\HEC\RAS\millcreek1.rep Asterisks for Borders
 There are several options 	(☐ Input Data (<u>General</u> <u>Summary</u> (X Plan Data X Manning's n Values (X Flow Data X Reach Lengths
available for the report	Geometric Data Contr. and Expan. Coefficients Output Profiles to Include in Report Set Profiles
content. The report generated	1.2.3 Specific Tables (Detailed Output) Cross Section Table Cutert Table Storage Area
can be viewed or the resulting	Bridge Table Storage Area Connection Multiple Openings Pump Stations Inline WeilTable Flow Distribution
file printed.	Stendard Table 2 Stendard Table 1
6	₩ Summary of Errors, Warnings and Notes
ITC	Close Generate Report View Report



<u>File Edit S</u> earch	<u>H</u> elp								
INPUT									-
Description:	80+00								
Station Eleva	tion Data	num=	6						
Sta E	lev St.	a Elev	Sta	Elev	Sta	Elev	Sta	Elev	
400	427 10 427	9 427	190	397	220	397	310	427	
Manning's n V	alues	num=	3						
Sta n	Val St	a n Val	Sta	n Val					
0	.04 10	0.035	310	- 84					
Bank Sta: Lef	t Right	Lengths	Loft (0 66	O	E	
10	0 310	Lengens	0 0	nannei Ø	RIGHT Ø	LUEFF	.1	.3	
10 Summary of Mai	0 310 NNING'S N	VALUES	0	nannei Ø	Right Ø	COUTT	.1	.3	
10 SUMMARY OF MA River:Mill Cro	0 310 NNING'S N	VALUES	0	nannei Ø	Kight Ø	LOEFF	.1	.3	
10 SUMMARY OF MAI River:Mill Cro Reach	0 310 NNING'S N eek Ri	VALUES ver Sta.	n1	namer 0	kight Ø	n3	.1	2.3	
10 SUMMARY OF MAI River:Will Cr Reach project area	0 310 NNING'S N eek Ri 1	VALUES ver Sta.	n1	. 04	kignt 0 n2 .035	n3 .04	.1	.3	_
10 SUMMARY OF MAN River:Mill Cro Reach project area project area	0 310 NNING'S N eek Ri 9	VALUES ver Sta. 00 9.5*	n1	. 84 . 94	kignt 0 n2 .035 .035	n3 .04 .04	.1	.3	_
10 SUHMARY OF MAI River:Mill Crr Reach project area project area project area	0 310 NNING'S N eek Ri 9 9	UALUES ver Sta. 00 9.5* 9.5	n1	. 84 . 84 . 84 . 84	kignt 0 -035 -035 -035 -035	n3 . 04 . 04 . 04	.1	-3	
10 SUMMARY OF MA River:Mill Cr Reach project area project area project area project area	0 310 NNING'S N eek Ri 9 9 9	VALUES Ver Sta. 00 9.5* 9.5* 8.5*	n1	- 84 - 84 - 84 - 84 - 84	Right 0 -035 -035 -035 -035 -035 -035	n3 . 04 . 04 . 04 . 04 . 04	.1	-3	_
10 SUMMARY OF MAI River:Mill Cr Reach project area project area project area project area project area	0 310 NNING'S N eek Ri 9 9 9 9 9 9 9	UALUES Ver Sta. 00 9.5 8.5 8.5 8.5 5 8.5	n1	. 04 . 04 . 04 . 04 . 04 . 04 . 04	kignt 0 - 035 - 035 - 035 - 035 - 035 - 035 - 035 - 035	n3 - 04 - 04 - 04 - 04 - 04 - 04	.1	-3	_
10 SUMMARY OF MA River:Will Cru Reach project area project area project area project area project area project area	0 310 NNING'S N eek Ri 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	VALUES Ver Sta. 00 9.5* 9.* 8.5* 8.* 7.5* 7.*	n1	. 04 . 04 . 04 . 04 . 04 . 04 . 04 . 04	Right 0 -035 -035 -035 -035 -035 -035 -035 -0	n3 - 84 - 84 - 84 - 84 - 84 - 84 - 84 - 84	.1	-3	1
10 SUHMARY OF MA River:Hill Cr Reach project area project area project area project area project area project area project area project area	0 310 NNING'S N eek Ri 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9	UALUES Ver Sta. 00 9.* 8.5* 8.* 8.* 7.5* 6.5*	n1	. 04 . 04 . 94 . 94 . 94 . 94 . 94 . 94 . 94 . 9	Right 0 .035 .035 .035 .035 .035 .035 .035 .0	n3 . 84 . 94 . 94 . 94 . 94 . 94 . 94	.1	-3	_

Hydraulic Model Accuracy

O

- Absolute accuracy: how good is your data? +/- 0.5 foot
- Relative accuracy: very good (compare one condition to another)

